

## Information + Instructions

### **ALGINAT Ki** Art.: 900360

#### Usage:

To cast all types of body parts, can also be used inside the mouth.

Is of the highest quality and purity – 100% dust-free.

Can be used directly on hair or skin.

#### Safety Precaution:

**ALGINAT Ki** may cause slight allergic reactions to persons sensitive to peppermint oil.

#### Processing instructions:

Mixing ratio: 20 g powder to 40 ml water

Using a water temperature of 15 ° C you should have about 3 minutes until the mixture begins to set.

Should you require a thicker or thinner mixture, reduce or increase the amount of water used.

It is compatible with dental cements.

#### Storage:

In an air-tight container, not above 25 °C.

#### Cleansing:

Ingenious ! simply wash off any remaining alginate with soap and warm water.

Our specialist Florian Schmidt-André will gladly provide further advice on usage at any time.