

## Plasticizer KI

Art. No. 500104

### Usage:

Plasticizer to make Silicone KI more elastic. (additional-curing)

### Safety Precautions:

Protect eyes, nose and mouth.

Keep out of reach of children.

Keep bottle tightly closed.

Protect from overheating.

Stock away from light.

### Processing:

For the production of a full head mask with a thickness of approx. 3 mm a total weight of 400 ml of silicone mix is necessary.

Now start the mixing.

This quantity follows from 100 ml silicone KI, component A and 100 ml silicone KI component B as well as the addition of 200 ml plasticizer KI. Mix the mixture well.

While the silicone mixture is still liquid, swill out your head form with the silicone mix.

Independent from the material of the form you need a release agent (Pros Tren KI for example).

At an average room temperature the curing or setting of the material is completed after 8 min.

### Special Tip:

For colouring we recommend our Flock or the product-related silicone colours.

### Important:

The maximum possible mixture is 1 (Silicone KI) to 2,5 (plasticizer).