

Information + Instructions

Latexmilk KI
Art.: 900360

Usage:

For casting and for creating prosthetic pieces.

Safety Precautions:

Do not bring in contact with eyes or insides of mouth, nose or ears.
Protect from frost and heat

Procedure:

A latex of the highest purity for creating rubber balds caps and firm, flexible pieces and masks.

Can be foamed and used to build-up surfaces. Int this case, the form must be rinsed with latex milk before use.

Tinting with pigment or colouring paste is possible (1 liter latex + 15 g colouring powder).

Before colouring clean carefully with a little spirit/alcohol.

Tips and tricks:

Vulkanizing possible.

Foaming can be achieved by the addition of cellulose emulsion.

e.g. mix 30 ml latexmilk with 5 ml cellulose-emulsion and dry in the oven between 60 and 85 °C.

Plaster moulds don't need to be pre-treated with separating agents.

Cleansing:

Any latex remaining on tools can simply be peeled-off when dry.

Our specialist Florian Schmidt-André will gladly provide further advice on usage at any time.