

## Instruction Sheet



### SKINELAST Ki

-elastic skin-  
Art. 500038

#### Usage:

Kerling's newly developed elastic skin, **SKINELAST** is a high quality, two component product used to create special effects on the surface of the skin.

The set is composed of: 1000grms component A, 300grms component B, 45grms **PROSTREM Ki**.

#### Safety tips:

Protect product from damp.

Keep tubs tightly closed.

Store in a cool place, (preferably in a refrigerator.)

Protect eyes, nose and mouth.

Keep out of reach from children.

Important: Contact with spirit alcohol will cause material to disintegrate!

#### Preparation:

Shake well before use.

Curing time after mixing and at a room temperature of 18°C: 3-5 mins.

Reformable, depending on thickness of material, after approx. 40 mins.

Volume ratio 1:1

Mixing ratio: 100grms A-component : 30grms B-component.

#### Tips and tricks:

Coat the negative moulds with **PROSTREM Ki** and allow to dry.

Mix the two components together quickly and thoroughly.

Rinse the inside of the negative mould with **SKINELAST Ki**.

When using larger moulds, rinse twice. The layers will bind together well.

A skin thickness measuring 1.5 – 3.0mm results in a far firmer skin than if, for example latex milk is used.

Colouring may commence using cosmetic pigments or suitable paints.

Always mix colour with component A.

Colouring materials should not contain spirit alcohol.

Further suggestions and information concerning usage available any time from our specialist consultant, Mr. Schmidt-Andre.